


CTM 24113 VOLVO VN, VNL - ACCESSORIES (INTERIOR PARTS)



- DETACH WITH KNIFE

- MAKE A HOLE

- GRIND

R - REPLACE

- OPTIONAL

2x - NUMBER OF WORKING STEPS

This set is not a children's toy and was designed for professional modellers only who already have some skills in working with photoetched parts. Special tools for bending of photoetched parts is recommended when working with this set. Non using this tool during bending may cause destruction of the part. Careful bending of the most of the parts could be also done using a metal ruler, a sharp knife and a tweezer on a hard surface. Pay attention, be careful and keep your safety and health in mind during work!

For gluing and filling a cyanoacrylate glue and a glue removing liquid is recommended. When (or even before) working with each part inspection of the real part on the vehicle or a picture of the real thing is recommended and helpful.

Modification of plastic parts may be required for proper use of some of the photoetched parts

CTM 24113 Volvo VN, VNL - accessories (interior parts)

1/Dashboard

2/Dashboard

3/Dashboard

4/Volvo Dealer logo

5/Dashboard

6/Volvo emblem and bar

7/Dashboard midlle part

8,9/ Door window controls (LH,RH)

10,11/Dashboard

12,13/Steering wheel controls

14/Dashboard

15/Dashboard loud speaker (RH)

16/Door loud speaker

17,18/Control buttons

19/Dashboard loud speaker (LH)

20/Volvo VN logo

21,22/Seatbelt locks

23/Seatbelts

