




CTM 24125 SCANIA LB - BADGES



CTM 24125 SCANIA LB - BADGES



- DETACH WITH KNIFE



- MAKE A HOLE



- BEND



- GRIND



- REPLACE



- OPTIONAL



- NUMBER OF WORKING STEPS

This set is not a children's toy and was designed for professional modellers only who already have some skills in working with photoetched parts. Special tools for bending of photoetched parts is recommended when working with this set. Non using this tool during bending may cause destruction of the part. Careful bending of the most of the parts could be also done using a metal ruler, a sharp knife and a tweezers on a hard surface. Pay attention, be careful and keep your safety and health in mind during work!

For gluing and filling a cyanoacrylate glue and a glue removing liquid is recommended. When (or even before) working with each part inspection of the real part on the vehicle or a picture of the real thing is recommended and helpful.

Modification of plastic parts may be required for proper use of some of the photoetched parts

CTM 24125 Scania LB - badges

- 1/ Fitting stencil for early grille type lettering
- 2/ Late type grille badge
- 3/ Early type lettering, to be used directly on the plastic part using the stencil, part No. 1
- 4,5/ 141 type badge w. separate lettering
- 6/ 140 type lettering (early grille type)
- 7/ 110 type lettering (early grille type)
- 8,9/ Late grille V8 logo badge W. separate lettering
- 10,11/ 111 type badge w. separate lettering
- 12/ Super badge, to be used as a decoration or to be used on JCL resin torpedo kits
- 13/ 85 type lettering (early grille type)
- 14/ V8 door logos, early version
- 15/ 80 type lettering (early grille type)
- 16/ Late type lettering, to be used on part No. 2
- 17/ Scania badges, to be used on the rear mudguards
- 18/ Scania lettering, to be used on old JCL resin torpedos kits
- 19/ Super badge (early grille type)
- 20,21,22,23,24/ 75,76 and Scania - Vabis lettering, to be used on old JCL resin torpedo kits
- 25/ 5
- 26/ 6